

Operating instructions

C9090-YJ
Gateway for Interbus PD

Germany

Siebert Industrieelektronik GmbH
Siebertstrasse, D-66571 Eppelborn
Phone +49 (0) 6806 980-0, Fax +49 (0) 6806 980-999
www.siebert.de, info@siebert.de

AUSTRIA

Siebert Österreich GmbH
Mooslackengasse 17, A-1190 Wien
Phone +43 (0)1 890 63 86-0, Fax +43 (0)14 890 63 86-99
www.siebert-oesterreich.at, info@siebert-oesterreich.at

© Siebert Industrieelektronik GmbH

Siebert®, LRD® and XC-Board® are registered trademarks of Siebert Industrieelektronik GmbH. All other product names mentioned herein may be the trademarks or registered trademarks of their respective owners.

Subject to change. – All rights reserved, including the rights of translation. No part of this document may in any form or by any means (print, photocopy, microfilm or any other process) be reproduced or by using electronic systems be processed, copied, or distributed without our written permission.

France

Siebert France Sarl
33 rue Poincaré, BP 90 334, F-57203 Sarreguemines Cédex
Phone +33 (0) 3 87 98 63 68, Fax +33 (0) 3 87 98 63 94
www.siebert.fr, info@siebert.fr

NETHERLANDS

Siebert Nederland B.V.
Korenmaat 12b, NL-9405 TJ Assen
Phone +31 (0)592-305868, Fax +31 (0)592-301736
www.siebert-nederland.nl, info@siebert-nederland.nl

SWITZERLAND

Siebert AG
Bützbergstrasse 2, Postfach 91, CH-4912 Aarwangen
Phone +41 (0)62 922 18 70, Fax +41 (0)62 922 33 37
www.siebert.ch, info@siebert.ch

Table of contents

Chapter 1	Safety precautions	
Chapter 2	Unit description	Function Principle circuit diagram Unit construction Parameterization Interbus-Interface Baud rate Serial Interface Menu display Status indicators
Chapter 3	Control	Data Transmission Handshake Flow chart Data segmentation Test mode
Chapter 4	Parameterization	Menu display Menu operation Menu table
Chapter 5	Technical data	Power supply Power consumption Ambient conditions Dimensions Weight

Chapter 1

Safety precautions



Bus errors may result in personal injury or material damage. Therefore it is to observe that activating the menu (see chapter 4) may cause a bus error.


Chapter 2

Unit description


Function

The gateway C9090-YJ serves for activating serial display panels and XT boards by the serial interface via Interbus PD. It has the function of a protocol converter and is built in the units ex factory.

Principle circuit diagram



Unit construction



Parameterization

The parameterization of the unit is done by means of a menu in the menu display (see chapter 4).

 Bus errors may result in personal injury or material damage. Therefore it is to observe that activating the menu may cause a bus error.

Interbus interface

The interbus interface (RS422) is located on the screw terminal strip of the interbus coupling. It has the following assignment:

Bus IN (incoming bus)			Bus OUT (outgoing bus)		
Termin. 1	/DO1	Inverted data output	Termin.7	PE	Protective Earth
Termin.2	DO1	Non inverted data output	Termin.8	/DO2	Inverted data output
Termin.3	/DI1	Inverted data input	Termin.9	DO2	Non inverted data output
Termin.4	DI1	Non inverted data input	Termin.10	/DI2	Inverted data input
Termin.5	GND	Signal ground	Termin.11	DI2	Non inverted data input
Termin.6	PE	Protective Earth	Termin.12	GND	Signal ground
			Termin.13	NC	-

The units are interbus slaves according to IEC 61158. On the bus, the units will use the ID code 03 (DIO).

The number of the assigned data words depends on the number of digits of the unit and on the data format selected in menu 1 (see chapter 3).

The incoming and outgoing bus are galvanically separated from each other.

Baud rate

The baud rate is defined by means of the jumper BR of the Interbus coupling (see block diagram):

Upper jumper	2 Mb/s
Lower jumper	500 kb/s

Serial interface

The serial interface is located on a flat cable connector. It is connected with the control computer of the display panel ex factory.

The serial interface has the RS485 4-wire format. The interface parameters are set in a menu (see chapter 4).

 The settings ex factory are to be found in the delivered documentation and so can be restored in case of a possible lost..

Menu display

The parameterization of the gateway is done by means of a menu in the menu display (see chapter 4).

In normal operation, the following status messages appear in the menu display::

```

on I nE      The gateway is parameterized on the bus and recognized as
participant.
--  ----    The gateway is not ready for communicating with the master.

```

Status displays

The status displays (LED) of the control computer and the Interbus coupling have the following meaning:

LED1	CC/RC	Connection is OK, master is not in RESET
LED2	BA	Bus is active
LED3	RD	Routing bus is disconnected
LED4	TR	No meaning
DATA		Data reception

Chapter 3 Interbus-Control

Data transmission The data transmission is done by sending cyclic process data (PD channel), which are written in the output data area. The number of output data bytes (2...20) is set in menu item 10 (see chapter 4).


The first byte in the input data area is needed for the handshake. The other data in the input data area are at random and without any meaning.

The data transmission via the PCP channel is not supported.


Handshake The system requires the data transmission in the Interbus to take place cyclically. Data located in the input and output areas of the master are exchanged cyclically between master and slave. This is why new data must be marked by the handshake as 'new'. The new data are applied once, whereas their cyclic repetition is ignored.

The handshake marks new data for the display (send handshake) and checks the receiving readiness of the display (busy check).


For the send handshake, bit 0 (TxHS bit) has been reserved in the first byte of the output data area (TxHS byte. Bits 7...1 must be set to 0 by the master.



For the busy check, bit 7 (RxHS bit) has been reserved in the only byte of the input data area (RxHS byte). Bits 6...0 are read by the master as 0.



Flow chart During the start, the master must set the TxHS bit to the value of the RxHS bit.



The display is ready to receive as soon as the RxHS bit has the same value as the TxHS bit sent last. Now the master can send new data to the display. The master marks new data by inverting the TxHS bit (toggle). After a short time, the display signals again readiness to receive by setting the RxHS bit equal to the TxHS bit received last.

Data segmentation	<p>The system requires the number of output bytes to be limited. This may require the division of a new data telegram into several segments. In accordance with the handshake method described above, each individual segment contains a send handshake byte (TxHS byte), and the maximum number of bytes it can contain is that configured in the output data area.</p> <p>The segments are sent in succession to the display in accordance with the handshake. The display evaluates the data after receipt of a message termination.</p> <p>Caution! If fewer data are sent to the display than configured in the output data area, excess output data bytes must be filled with 0x00, irrespective of whether data is segmented or not. Data bytes containing 0x00 are ignored.</p>
Test mode	<p>In order to test the correct connection of the display panel, the gateway contains a test function. For activation of the test mode press the menu key [*] for approx. 5 s.</p> <p>In test mode the gateway displays alternating character strings in form of 1111111111<CR><LF> every second and indicates them on the menu screen. The figures are run from 0 to 9. The output is effected with the interface parameters set in the menu.</p> <p>The test mode is terminated by switching the gateway off and on.</p> <p>The display panel cannot be activated in test mode.</p>

Chapter 4 Parameterization



Bus errors may result in personal injury or material damage. Therefore it is to observe that activating the menu may cause a bus error.

Menu	<p>The parameterization of the gateway is carried out in a menu of the menu display. In normal operation, the status messages appear in the menu display (see chapter 1).</p>																
Menu operation	<p>To reach the menu, press both menu buttons simultaneously (approx. 1 sec.) until an audible signal is heard and menu item 01 appears in the menu display. Now, you can navigate in the menu as follows:</p> <table border="0" style="width: 100%;"> <tr> <td style="padding-right: 20px;">Next menu item:</td> <td>Shortly press key [↕]</td> </tr> <tr> <td>Page menu items forward:</td> <td>Press key [↕] long</td> </tr> <tr> <td>Previous menu item:</td> <td>Double click on key [↕]</td> </tr> <tr> <td>Page menu items backward:</td> <td>Double click on [↕] and keep it pressed</td> </tr> <tr> <td>Next setting</td> <td>Shortly press key [↔]</td> </tr> <tr> <td>Page settings forward:</td> <td>Press key [↔] long</td> </tr> <tr> <td>Previous setting</td> <td>Double click on key [↔]</td> </tr> <tr> <td>Page setting backward:</td> <td>Double click on [↔] and keep it pressed</td> </tr> </table>	Next menu item:	Shortly press key [↕]	Page menu items forward:	Press key [↕] long	Previous menu item:	Double click on key [↕]	Page menu items backward:	Double click on [↕] and keep it pressed	Next setting	Shortly press key [↔]	Page settings forward:	Press key [↔] long	Previous setting	Double click on key [↔]	Page setting backward:	Double click on [↔] and keep it pressed
Next menu item:	Shortly press key [↕]																
Page menu items forward:	Press key [↕] long																
Previous menu item:	Double click on key [↕]																
Page menu items backward:	Double click on [↕] and keep it pressed																
Next setting	Shortly press key [↔]																
Page settings forward:	Press key [↔] long																
Previous setting	Double click on key [↔]																
Page setting backward:	Double click on [↔] and keep it pressed																

The menu ends in menu item 99 with the button [↕]. The settings made are either saved (set), not saved (escape) or the factory settings are reset, depending on the setting selected in menu item 99.

Canceling the menu without saving the settings made is possible by pressing both menu buttons longer (approx. 1 sec.) or will occur automatically if 60 seconds pass without a menu button being pressed.

Once the menu is closed, the gateway behaves in the same manner as when the operating voltage was applied.

In menu operation an activation of serial end units connected in series is not possible.

Menu table

The menu items are displayed in the following menu table. The factory settings are marked with an *. Individual menu items or settings can be suppressed in another menu item, depending on the unit version or setting.

Menu item	Settings	Menu display
01 Baud rate	1200	01 1200
	2400	01 2400
	4800	01 4800
	9600*	01 9600
	19200	01 192
	38400	01 384
	57600	01 576
	115200	01 1152
02 Data format	7 bit	02 7b iE
	8 bit*	02 8b iE
03 Parity	No parity*	03 nonE
	odd parity	03 odd
	even parity	03 EvEn
04 Handshake (serial interface)	No Handshake*	04 noHS
	XON/XOFF-Handshake	04 onoF
10 Number of output data bytes	2	10 2
	4	10 4
	6	10 6
	↓	↓
	20	10 20
99 Saving	Saving parameters* (Set)	99 SEt
	Not saving parameters (Escape)	99 ESC
	Resetting to the default settings (Default)	99 dEF

Chapter 5**Technical data**

Power supply	C9090-YJ-01	3,3 V DC
	C9090-YJ-02	5 V DC
	C9090-YJ-03	12...24 V ±15% DC
Power consumption max.	4 VA	
Ambient conditions	Operating temperature:	0...50 °C
	Storage temperature:	-30...85 °C
	Relative humidity:	95 % (non-condensing)
Dimensions	108,9 x 108 mm (B x H)	
Weight approx.	125 g	