

# safety displays



With USB interface



Socket type C



The USB socket is located on the lower left side of the display

SERIES  
XC600-XXX-X-03

The control takes place via a supplied PC software. During commissioning, it is used to set the number of accident-free days to the current value. Thereafter, this value automatically increases by another day every 24 hours. If an accident occurs, the displayed accident-free days can be set to zero from the PC.

The displays are equipped with a USB interface for connection to a PC. The configuration and the changing of values is carried out via the USB interface. A matching USB cable is included in delivery.

The connection can also be established via Bluetooth (except for the XC610 and XC620 Series). Optionally the displays are available with Ethernet TCP/IP interface so that they can be integrated into a network.

Alternatively, to the control with a PC software the displays are optionally available for control with an infrared remote control.



Socket type C

